Chevrolet and GMC Trucks

Includes Chevrolet Lumina APV, Oldsmobile Bravada and Silhouette, Pontiac Trans Sport

Note: *Caster adjustments vary with the ride height, which is measured between the frame crossmember and the bracket mount for the lower control arm bumper, and is known as Dimension "A". Vehicle must be parked on a smooth, level surface when the measurement is taken.*

Astro and Safari

1985 thru 1987
- Caster ..... 2.70-degree(s)
- Camber ..... 0.90-degree(s)
- Toe-in 5/32-inch

1988 thru 1996
- 2WD
  - Caster ..... 2.70-degree(s)
  - Camber ..... 0.80-degree(s)
  - Toe-in 7/64-inch
- 4WD (1988 thru 1990)
  - Caster ..... 3.00-degree(s)
  - Camber ..... 0.88-degree(s)
  - Toe-in ..... -3/64-inch
- 4WD (1991 thru 1996)
  - Caster ..... 2.00-degree(s)
  - Camber ..... 0.88-degree(s)
  - Toe-in ..... -1/32-inch

Lumina APV, Silhouette and Trans Sport

1990 thru 1992
- Front
  - Caster ..... 1.70-degree(s)
  - Camber ..... 0-degree(s)
  - Toe-in 0-inch
- Rear
  - Camber ..... -0.10-degree(s)
  - Toe-in 0-inch

1993 thru 1996
- Front
  - Caster ..... 3.00-degree(s)
  - Camber ..... 0-degree(s)
  - Toe-in 0-inch
- Rear
  - Camber ..... -0.10-degree(s)
  - Toe-in 0-inch

S10, S15, Sonoma, S-Blazer, S-Jimmy and Bravada

1983 thru 1994
- 2WD
  - Caster ..... 2.00-degree(s)
  - Camber ..... 0.80-degree(s)
  - Toe-in 5/32-inch
- 4WD
  - Caster ..... 2.00-degree(s)
  - Camber ..... 0.80-degree(s)
  - Toe-in 5/32-inch

1995 and 1996
- 2WD
  - Caster ..... 3.00-degree(s)
  - Camber ..... 0-degree(s)
  - Toe-in 7/64-inch
- 4WD
  - Caster ..... 3.00-degree(s)
  - Camber ..... 0-degree(s)
  - Toe-in 7/64-inch
- Typhoon
  - Caster ..... 3.50-degree(s)
  - Camber ..... 0-degree(s)
  - Toe-in 5/32-inch

C-R10, 20 and 30 Pickups; Suburban (2WD)

1983 thru 1988
- C-R10
  - Caster
    - Dimension A
      - 2-1/2 inches ..... 3.70-degree(s)
      - 3 inches ..... 3.20-degree(s)
      - 3-1/2 inches ..... 2.63-degree(s)
      - 4 inches ..... 2.12-degree(s)
      - 4-1/2 inches ..... 1.50-degree(s)
      - 5 inches ..... 1.00-degree(s)
    - Camber ..... 0.70-degree(s)
    - Toe-in 3/16-inch
- C-R 20 and 30
  - Caster
    - Dimension A
      - 2-1/2 inches ..... 1.50-degree(s)
      - 3 inches ..... 0.88-degree(s)
      - 3-1/2 inches ..... 0.30-degree(s)
      - 4 inches ..... 0-degree(s)
      - 4-1/2 inches ..... -0.70-degree(s)
      - 5 inches ..... -1.20-degree(s)
    - Camber ..... 0.25-degree(s)
    - Toe-in 3/16-inch

1989 thru 1991
- R10
  - Caster
    - Dimension A
      - 2-1/2 inches ..... 3.70-degree(s)
      - 3 inches ..... 3.20-degree(s)
      - 3-1/2 inches ..... 2.63 degree(s)
      - 4 inches ..... 2.12-degree(s)
      - 4-1/2 inches ..... 1.50-degree(s)
      - 5 inches ..... 1.00-degree(s)
    - Camber ..... 0.70-degree(s)
    - Toe-in 5/64-inch
- R20 and 30
  - Caster
    - Dimension A
      - 2-1/2 inches ..... 1.50-degree(s)
      - 3 inches ..... 0.88-degree(s)
      - 3-1/2 inches ..... 0.30-degree(s)
      - 4 inches ..... 0-degree(s)
      - 4-1/2 inches ..... -0.70-degree(s)
      - 5 inches ..... -1.20-degree(s)
    - Camber ..... 0.25-degree(s)
    - Toe-in 5/64-inch

K-V10, 20 and 30 series Pickups; Blazer, Jimmy and Suburban (4WD)

1983 and 1984
- Caster
  - Dimension A
    - 4 inches ..... 8.00-degree(s)
  - Camber ..... 1.00-degree(s)
  - Toe-in 3/16-inch

1985 thru 1988
- Caster
  - Dimension A
    - 4 inches ..... 8.00-degree(s)
  - Camber ..... 1.50-degree(s)
  - Toe-in 0-inch

1989
- Caster
  - Dimension A
    - 4 inches ..... 8.00-degree(s)
  - Camber ..... 1.50-degree(s)
  - Toe-in 5/64-inch